



QUASAR KIT # 3122ADT - 90S4434/8535 Adaptor Board for Kit 3122



To 40 pin socket on 3122 board

90S4434/8535 Programming socket



ASSEMBLY INSTRUCTIONS

1. Mount the 20-pin header strips on the solder side of the PCB. The 'short' end fits into the PCB. Solder from the component side of the PCB. Before soldering make sure that the pins are vertical and at 90° to the PCB.
2. Fit the 40 pin socket (normal or ZIF) to the solder side of the PCB. Cut off the "tops" of the header strips so that the socket can sit as closely to the board as possible. Solder the socket into place from the solder side. Take care not to get any solder onto the header strips.