


## QUASAR ELECTRONICS KIT No. 1028 4 Watt FM TRANSMITTER

### Audio / Microphone Input Connection

For testing purposes we supply the transmitter with an electret microphone. This type of microphone requires a small DC bias to work so a 47K (yellow, Violet, Orange) resistor is also provided. This must be connected between the positive rail and the audio signal pin 2 (easiest done on the solder side of the PCB).

However, for best results use either a piezoelectric microphone or the line of a tape recorder, preamp or mixer (kit [1052](#) is suitable) for the audio input. If you use the transmitter with one of these latter audio sources you must remove the 47K resistor.



If you want to learn more about transmitters and how they work look at the following page on our website:

<http://www.quasarelectronics.com/kit-files/data-shfts/fmtx.htm>

### Ordering

For pricing info and online ordering please visit:

<http://www.quasarelectronics.com/1028.htm>

For further info please contact us by e-mail:

[mailto: sales@QuasarElectronics.com](mailto:sales@QuasarElectronics.com)

**COPYRIGHT** © 2003 Quasar Electronics Limited. All rights reserved. Reproduction of this document in whole or in part in any form or medium without express written permission of Quasar Electronics Limited is prohibited.

E&OE